

S.C.U.R.D.I.A.

FOH	INSTRUMENT	MIC	NOTES \ STANDS	CH	
1.	Cajon	SM91, ADX60		1.	O
2.	Darabuka, Djembe	D4, SM57, 421	small	2.	O
3.	Tamburin	XLR	clip	3.	O
4.	Perc OH 1	Schoeps, 414, Neumann	big	4.	O
5.	Surdo	D4, SM57, 421	big	5.	O
6.	Timbale	D4, SM57, 421	big	6.	O
7.	Conga	D4, SM57, 421	small, clamp	7.	O
8.	Conga	D4, SM57, 421	small, clamp	8.	O
9.	Perc OH 2	Schoeps, 414, Neumann	big	9.	O
10.	Perc OH 3	Schoeps, 414, Neumann	big	10.	O
11.	Leslie Bottom	D4, 421	small	11.	O
12.	Leslie Top	D2, SM57, 421	big	12.	O
13.	Leslie Top	D2, SM57, 421	big	13.	O
14.	Key L	Di			
15.	Key R	Di		14.	O
16.	Tuba	dpa, ADX20	Clip	15.	O
17.	Klarinette	TLM, PL20, AT4033	big	16.	O
18.	Sax	TLM, PL20, AT4033	big	17.	O
19.	Piano Bass	SCX25A	Clamp	18.	O
20.	Piano Diskant	SCX25A	Clamp	19.	O
21.	Piano Mon	SM58, C Ducer		20.	O
22.	Akkordeon Diskant	XLR		21.	O
23.	Akkordeon Bass	XLR		22.	O
24.	Oud	Di		23.	O
25.	Gitarre	Di		24.	O
26.	Cello	dpa, Schoeps, Neumann	clip / small	25.	O
27.	Violine	dpa 4099	Clip	26.	O
28.	Vox Piano	Sennheiser, Shure	big \ 3000, UHF-R	27.	O
29.	Vox Oud	SM86, OM6, e945	big	28.	O
30.	Vox Violine	SM86, OM6, e945	big	29.	O
31.	Vox Cello	SM86, OM6, e945	big	30.	O
32.	Vox Akk	SM86, OM6, e945	big	31.	O
33.	Vox Center	Sennheiser, Shure	big \ 3000, UHF-R	32.	O
34.				33.	O
35.				34.	O
36.				35.	O
37.				36.	O
38.				37.	O
39.	FX 1 Return L		Rev Plate	38.	O
40.	FX 1 Return R		Rev Plate	39.	O
41.	FX 2 Return L		Rev Hall short	40.	O
42.	FX 2 Return R		Rev Hall short	41.	O
43.	FX 3 Return L		Rev Hall kurdish mountains	42.	O
44.	FX 1 Return R		Rev Hall kurdish mountains	43.	O
45.	FX 4 Return L			44.	O
46.	FX 4 Return R			45.	O
47.	Music L		FOH music for doors-intro-outr	46.	O
48.	Music R		FOH music for doors-intro-outr	47.	O